

PTC-101 Series Quick Installation Guide

Moxa Industrial Media Converter

Version 5.2, January 2021

Technical Support Contact Information
www.moxa.com/support

MOXA[®]

© 2021 Moxa Inc. All rights reserved.

P/N: 1802001016016



Overview

Moxa's PTC-101 industrial media converters are specially designed for reliable and stable operation in harsh industrial environments, and provide industrial grade media conversion between 10/100BaseT(X) and 100BaseFX. The PTC-101's reliable industrial design is excellent for keeping your industrial automation applications running continuously, and comes with a relay output warning alarm to help prevent damage to your equipment.

This product has a wide -40 to 85°C operating temperature range, and is designed to withstand a high degree of vibration and shock. The rugged hardware design makes the PTC-101 perfect for ensuring that your Ethernet equipment can withstand critical industrial applications, such as in hazardous locations, and complies with FCC, UL, and CE standards.

Package Checklist

The PTC-101 is shipped with the following items. If any of these items is missing or damaged, please contact your customer service representative for assistance.



- Moxa Industrial Media Converter
- Quick installation guide (printed)
- Warranty card

Features

- Supports 10/100Base-TX auto-negotiation and auto-MDI/MDI-X
- Multi-mode and single mode with SC, ST, or LC fiber connectors available
- Supports Link Fault Pass-Through
- Power failure by relay output (LV model only)
- Redundant dual VDC power inputs
- -40 to 85°C operating temperature range
- Integrated high-reliability power supply eliminates the need for external power transformer


Panel Layout of the PTC-101 Series

Top Panel View




1. Grounding screw
2. Terminal block for power input
3. Heat dissipation vents and relay output
4. DIP switch
5. Power input PWR LED
6. Fiber Link/Active LED
7. 100BaseFX Port (ST/SC/LC connector)
8. 10/100BaseT(X)
9. TP port 10 Mbps LED
10. TP port 100 Mbps LED
11. Model Name
12. DIN-Rail mounting kit


Front Panel View (PTC-101-M-ST-LV)




Front Panel View (PTC-101-S-SC)




Rear Panel View




Rear Panel View




Dimensions (for the PTC-101-S-SC; other models available by request)




Side View (HV Models)



Side View (LV Models)



Front View



Rear View

Panel Mounting Kit (Optional)

Wiring Requirements



ATTENTION

Safety First!

Be sure to disconnect the power cord before installing and/or wiring your Moxa Industrial Media Converter.



ATTENTION

Safety First!

Calculate the maximum possible current in each power wire and common wire. Observe all electrical codes dictating the maximum current allowable for each wire size. If the current goes above the maximum ratings, the wiring could overheat, causing serious damage to your equipment.

You should also pay attention to the following:

- Use separate paths to route wiring for power and devices. If power wiring and device wiring paths must cross, make sure the wires are perpendicular at the intersection point.
NOTE: Do not run signal or communications wiring and power wiring in the same wire conduit. To avoid interference, wires with different signal characteristics should be routed separately.
- You can use the type of signal transmitted through a wire to determine which wires should be kept separate. The rule of thumb is that wiring that shares similar electrical characteristics can be bundled together.
- Keep input wiring and output wiring separated.
- We strongly advise labeling wiring to all devices in the system.

Grounding the Moxa Industrial Media Converter

Grounding and wire routing help limit the effects of noise due to electromagnetic interference (EMI). Run the ground connection from the ground screw to the grounding surface prior to connecting devices.




ATTENTION

This product is intended to be mounted to a well-grounded mounting surface such as a metal panel.

Wiring the AC/DC Power Inputs for the

PTC-101-HV series



Top View



STEP 1: Insert the negative/positive AC/DC wires into the V-/V+ terminals.

STEP 2: To keep the AC/DC wires from pulling loose, use a small flat-blade screwdriver to tighten the wire-clamp screws on the front of the terminal block connector.

STEP 3: Insert the plastic terminal block connector prongs into the terminal block receptor, which is located on the PTC-101-HV's top panel.

Wiring the Redundant Power Inputs for the PTC-101-LV series

The top five contacts of the 8-contact terminal block connector on the PTC-101-LV's top panel are used for the PTC-101-LV's two DC inputs. Top and front views of one of the terminal block connectors are shown here.



STEP 1: Insert the negative/positive DC wires into the V-/V+ terminals.

STEP 2: To keep the DC wires from pulling loose, use a small flat-blade screwdriver to tighten the wire-clamp screws on the front of the terminal block connector.

STEP 3: Insert the plastic terminal block connector prongs into the terminal block receptor, which is located on the PTC-101-LV's top panel.



ATTENTION

Before connecting the PTC-101-LV to the DC power inputs, make sure the DC power source voltage is stable.

Communication Connections

PTC-101 models have one 10/100BaseT(X) Ethernet port, and one 100BaseFX (SC, ST, or LC type connector) fiber port.

10/100BaseT(X) Ethernet Port Connection

The 10/100BaseT(X) ports located on the PTC-101's front panel are used to connect to Ethernet-enabled devices.

Below we show pinouts for both MDI (NIC-type) ports and MDI-X (HUB/Switch-type) ports, and also show cable wiring diagrams for straight-through and cross-over Ethernet cables.

10/100Base T(x) RJ45 Pinouts


MDI Port Pinouts

Pin	Signal
1	Tx+
2	Tx-
3	Rx+
6	Rx-


MDI-X Port Pinouts

Pin	Signal
1	Rx+
2	Rx-
3	Tx+
6	Tx-


8-pin RJ45



RJ45 (8-pin) to RJ45 (8-pin) Straight-Through Cable Wiring



RJ45 (8-pin) to RJ45 (8-pin) Cross-Over Cable Wiring




100BaseFX Ethernet Port Connection


The concept behind the SC port and cable is quite straightforward. Suppose you are connecting devices I and II. Contrary to electrical signals, optical signals do not require a circuit in order to transmit data. Consequently, one of the optical lines is used to transmit data from device I to device II, and the other optical line is used to transmit data from device II to device I, for full-duplex transmission.

All you need to remember is to connect the Tx (transmit) port of device I to the Rx (receive) port of device II, and the Rx (receive) port of device I to the Tx (transmit) port of device II. If you are making your own cable, we suggest labeling the two sides of the same line with the same letter (A-to-A and B-to-B, as shown below, or A1-to-A2 and B1-to-B2).


SC-Port Pinouts




SC-Port to SC-Port Cable Wiring



ST-Port Pinouts




ST-Port to ST-Port Cable Wiring



Redundant Power Inputs

For the PTC-101-LV series, both power inputs can be connected simultaneously to live DC power sources. If one power source fails, the other live source acts as a backup, and automatically supplies all of the Moxa Industrial Media Converter's power needs.

DIP Switch Setting



DIP No.	Function	ON	OFF
1	Auto Negotiation	Enable	Disable
"ON": Enables the "Auto Negotiation" function. The speed and duplex states for each port link segment are automatically configured using the highest performance interoperation mode. "OFF": Disables the "Auto Negotiation" function. The speed and duplex states depend on the manual setting configuration.			
2	Force TP Speed	100Mbps	10Mbps
(Only when Auto Negotiation is disabled) "ON": Forces the Ethernet port to use 100 Mbps transmission. "OFF": Forces the Ethernet port to use 10 Mbps transmission.			
3	Force TP Duplex	Full Duplex	Half Duplex
(Only when Auto Negotiation is disabled) "ON": Forces the Ethernet port to use Full Duplex. "OFF": Forces the Ethernet port to use Half Duplex.			
4	Link Fault Pass Through	Enable	Disable
"ON": Enables "Link Fault Pass Through." The link status on the TX port will inform the FX port of the same device and vice versa. "OFF": Disables "Link Fault Pass Through." The link status on the TX port will not inform the FX port.			
5	Operating Mode	Store-and-Forward	Pass Through
"ON": Selects "Store-and-Forward" mode. Begins to forward packets to a destination port after an entire packet is received. The latency depends on the packet length. "OFF": Selects "Pass Through" mode. Operates with the minimum latency. Both transceivers are interconnected via internal MIIs and the internal switch engine and data buffer are not used. Note: With "Pass Through" mode enabled, the Ethernet port and fiber port should transmit at 100 Mbps, which is equivalent to full duplex mode.			

The default setting for all DIP switches is in the ON position.



ATTENTION

After changing the DIP switch setting, you will need to power off and then power on the PTC-101 to activate the new setting.

LED Indicators

The front panel of the Moxa Industrial Media Converter contains several LED indicators. The function of each LED is described in the table below.

LED	Color	State	Description
PWR1	Green	On	Power is being supplied to power input PWR1
		Off	Power is not being supplied to power input PWR1
PWR2	Green	On	Power is being supplied to power input PWR2
		Off	Power is not being supplied to power input PWR2
Fiber/ Link/ Act	Green	On	Fiber port is active
		Blinking	Data is being transmitted or received.
		Off	Fiber is inactive
10M	Yellow	On	Ethernet port 100 Mbps link is active
		Blinking	Data is being transmitted at 10 Mbps
		Off	Ethernet port 10 Mbps link is inactive
100M	Green	On	Ethernet port 100 Mbps is active
		Blinking	Data is being transmitted at 100 Mbps
		Off	Ethernet port 100 Mbps link is inactive

Specifications

Technology			
Standards	IEEE 802.3 for 10BaseT IEEE 802.3u for 100BaseT(X), 100BaseFX		
Interface			
RJ45 ports	10/100BaseT(X)		
Fiber ports	100BaseFX (SC/ST/LC connectors)		
LED Indicators	PTC-101-HV series: PWR1, Fiber Link, 10/100M (TP port) PTC-101-LV series: PWR1, PWR2, Fiber Link, 10/100M (TP port)		
Dip Switches:			
Dip No.	Function	ON	OFF
1	Auto Negotiation	Enable	Disable
2	Force TP Speed	100 Mbps	10 Mbps
3	Force TP Duplex	Full Duplex	Half Duplex
4	Link Fault Pass Through	Enable	Disable
5	Operating Mode	Store-and-Forward	Pass Through
The default setting for all DIP switches is in the ON position.			
Alarm Contact	One relay output with current carrying capacity of 1 A @ 24 VDC		

Optical Fiber:			
		100BaseFX	
		Multi-mode	Single-mode
Wavelength		1300 nm	1310 nm
Max. TX		-10 dBm	0 dBm
Min. TX		-20 dBm	-5 dBm
RX Sensitivity		-32 dBm	-34 dBm
Link Budget		12 dB	29 dB
Typical Distance		5 km ^a 4 km ^b	40 km ^c
Saturation		-6 dBm	-3 dBm
a. 50/125 μ m, 800 MHz*km fiber optic cable			
b. 62.5/125 μ m, 500 MHz*km fiber optic cable			
c. 9/125 μ m, 3.5 PS/(nm*km) fiber optic cable			
Power Requirements			
Input Voltage:			
Power Supply Type		Power Consumption	Fuse Rating
LV-DC	20 VDC to 72 VDC	170 mA @ 20 VDC	3.15A(T) 2
HV-AC	85 VAC to 264 VAC	73 mA @ 85 VAC	3.15A(T) 2
HV-DC	88 VDC to 300 VDC	47 mA @ 88 VDC	3.15A(T) 2
Connection		Removable Terminal Block	
Overload Current Protection		1.6 A (protects against two signals shorted together)	
Reverse Polarity Protection		Present	
Physical Characteristics			
Housing		Aluminum, IP30 protection	
Dimensions (W x H x D)		122.5 x 90 x 20 mm (4.82 x 3.54 x 0.79 inch)	
Weight		Product only: 690 g Packaged: 875 g	
Environmental Limits			
Operating Temperature		-40 to 85°C (-40 to 185°F)	
Storage Temperature		-40 to 85°C (-40 to 185°F)	
Operating Humidity		5 to 90%	
Regulatory Approvals			
Safety		UL 60950-1	
EMI		FCC Part 15, CISPR (EN55032) class A	
EMS		EN61000-4-2 Edition 1.2: 2001-04 (Level 4) EN61000-4-3: 1995+A1: 2001 IEC 61000-4-3: 2002+A1: 2002 (Level 3) EN61000-4-4: 2004 (Level 4) EN61000-4-5: 2001-04 (Level 3) EN61000-4-6: 2004-11 (Level 3) EN61000-4-8: 2001-03 (Level 5) EN61000-4-11: 2004-03 (Criteria B)	
Power Automation		IEC 61850-3, IEEE 1613	
Rail Traffic		EN50155/EN50121-4	
Warranty			
Warranty Period		5 years	
Details		See www.moxa.com/warranty	